


Create a license request without NCspeed

1. Plug the USB-Dongle to your computer
2. Open the CodeMeter Control Center (should be installed automatically together with dongle driver)
3. You will see a window like that



4. Please, select your dongle and click onto the “License Update”-button.
5. Select “Next”

